ATTENTION:

The motor of your Majestic® is thermally protected. If overheating occurs, it will automatically stop running to prevent damage. If this occurs, shut power unit off, remove cord from wall outlet. Let unit cool. This condition may be caused by obstructed air flow. Check for a blockage in the attachment, hose or wand. The filters may also need to be replaced. If you have checked for the above, and the condition persists, take the unit to your local authorized service center.

NOTE: The motor will resume operating once properly cooled.

TARLE OF CONTENTS.

WARNING-TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK, OR INJURY: Do not use perfume or alcohol-based liquids in the FILTERQUEEN® Majestic®. Use Genuine Health-Mor/FILTERQUEEN® Fragrances sparingly-DO NOT SATURATE scent pad. Use of non-genuine Health-Mor/FILTERQUEEN® scents/fragrances in any manner other than described in the owner's manual could cause damage to your motor, and will void your warranty.


This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

If the supply cord is damaged, it must be replaced by the manufacturer or an authorized FILTERQUEEN® Distributor.

DACE

INDEE OF CONTENTS.	mol
Majestic® Parts	2 - 3
Air Scenting Chamber	
Assembly/Operations	5
Power Nozzle	
Attachments	8 - 9
Changing the Filters	10
Warranty	
Lifetime Service Benefit	

• For immediate service and information, your local Distributor is:



MAJESTIC® PARTS

- 1. On/Off Switch Contains the international symbols "I" for ON and "0" for OFF.
- 2. Exhaust Cap Remove to convert the Majestic® to an efficient blower.
- 3. Caution Light Lights up when the motor has overheated. Motor automatically shuts off to prevent damage. Turn the Majestic® off and unplug cord from wall. Let unit cool. This condition is usually caused by an obstructed air flow. Check for blockages in the hose, wand, or attachments. Filter may also need to be replaced. If the problem persists, take the Majestic® to an Authorized Service Center.
- **4. Scent Chamber** Use one of Majestic's® Scents to freshen the air in your home while you clean.
- **5. Suction Inlet** *Use to connect hose to unit. Helps impart cyclonic action.*
- **6.** Clamp Keeps an air tight seal between the power unit and dirt container, yet opens quickly and easily.
- 7. Caster Set Rubber ball casters roll smoothly on rugs or hard surfaces. Always align one caster under suction inlet to prevent tipping.
- **8. Power Nozzle Outlet** *Plug in for electric hose*.
- **9.** Attachment Crown Holds four of the most essential cleaning attachments within easy fingertip reach.











MAJESTIC® PARTS

- **10. Upholstery Nozzle and Brush** *Remove imbedded dirt from overstuffed furniture, mattresses, and drapes.*
- 11. Crevice Tool Reach hard to reach places.
- 12. Dusting Brush Eliminates the need for a dust cloth.
- **13. Bare Floor Brush** Cleans hardwood, tile, linoleum, and other hard surfaced floors.
- **14. Power Nozzle Attachment Kit** *Includes Power Nozzle electric hose power wand*









AIR-SCENTING CHAMBER

Using the air-scenting chamber

- 1. Remove exhaust cap on top of Majestic® with a slight turn to the left and lift off.
- 2. Mist the grey felt air-scent pad with one or two sprays of your desired Genuine Health-Mor/FILTERQUEEN® Fragrance.

WARNING-TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK, OR INJURY: Do not use perfume or alcohol-based liquids in the FILTERQUEEN® Majestic®. Use Genuine Health-Mor/FILTERQUEEN® Fragrances sparingly-DO NOT SATURATE scent pad. Use of non-genuine Health-Mor/FILTERQUEEN® scents/fragrances in any manner other than described in the owner's manual could cause damage to your motor, and will void your warranty.

- 3. Close air-scent chamber by replacing cap and locking with a slight turn to right until it locks into place.
- 4. Start power unit and resume cleaning. Within minutes you will notice the effects of your Majestic* air-scenting chamber throughout the room.









ASSEMBLY AND OPERATION

For suction operation:

- 1a. Connect hose to suction inlet on dirt container by lining up arrow on hose with metal pins on inlet and lock with a quarter turn to the right.
- 2a. Connect wand or cleaning attachment to hose by inserting male end into hose and rotating it until the attachment or wand snaps into place.
- 3. Use accessories as recommended on the following pages.

For blowing operation:

- 1b. Remove the exhaust cap with a quarter turn to the left.
- 2b. Connect hose to inlet on top of unit by lining up arrow on hose with metal pins on inlet and lock with a quarter turn to the right.
- Connect wand or cleaning attachment to hose by inserting male end into hose and rotating it until the attachment or wand snaps into place.
- 4. Use accessories as recommended on the following pages.







POWER NOZZLE

ATTACHING POWER NOZZLE:

- 1. Assemble for suction cleaning.
- 2. Connect wand to nozzle by pushing the female end of the wand over the male end of the swivel neck of the nozzle until the locking button of the wand snaps into place. The wand swivels more than 90 degrees allowing it to lie flat on the floor.
- 3. Plug cord extending from other end of hose into the outlet on the power unit.

PLEASE NOTE: The "ON/OFF" markings on the hose feature the international symbols of "I" for ON and "O" for OFF. This switch only controls turning the power nozzle on or off. To turn the power nozzle ON (for carpets) slide the switch to the most forward position. To turn the power nozzle OFF (for wood, tile and linoleum floors) slide the switch to the rear position.

NOTICE: This hose contains electrical wires

POWER NOZZLE

A. CLEANING WITH THE POWER NOZZLE:

The Majestic® power nozzle requires no rug surface height adjustment. The shape of the power nozzle body has been specially designed to allow it to be effective on any rug or bare floor surface.

Use long, slow strokes when cleaning. For thicker rugs, use a criss-cross pattern to raise nap and give them a fluffier appearance.

To clean stairs:

- Remove caster set from power unit.
- Set Majestic® on landing.
- Remove wand and connect hose handle directly to power nozzle.

STORAGE: Avoid sharp bends in hose by removing hose from the unit before storing.

CAUTION: Do not use on carpets or rugs with fringe or loose fibers.







B. PERIODIC MAINTENANCE:

Power nozzle:

There are no user serviceable parts within the Majestic® power nozzle. Should any issue arise that requires service, please contact your local FILTERQUEEN® Distributor for service.

Note that your power nozzle roller brush must be replaced periodically in order to maintain maximum cleaning performance. Contact your local FILTERQUEEN® Distributor for service.

Power nozzle resettable circuit breaker:

The circuit breaker is designed to protect the motor of the power nozzle from damage, should it become clogged or the revolving brush stalls. To reset the circuit breaker, turn off the Majestic® and unplug cord from wall outlet. Remove any foreign objects from power nozzle and press the red button on the back of the nozzle. Plug Majestic® in and resume use.

C. Power unit caution light:

When lit, the caution light indicates that the motor of the power unit has overheated. The motor automatically shuts off to prevent damage. Turn Majestic® off and unplug cord from wall. Let unit cool. This condition is usually caused by an obstructed air flow. Check for blockages in the hose, wand, or attachments. Filters may also need to be replaced. If the problem persists take the Majestic® to an Authorized Service Center.









ATTACHMENTS

A. THE DUSTING BRUSH: For easy dusting

Assemble Majestic® for suction cleaning.

Do all your general dusting with the round brush – it virtually eliminates your need for a dust cloth. Use on highly-polished furniture, the most delicate cloth lampshades, or any surface where dust accumulates.

For general room dusting: Attach brush directly to hose. Clean with gentle short strokes; do not press down hard as this will seal the opening and cut off your cleaning power.

To clean brush: Run open end of hose over bristles of brush. If you have been dusting grimy or very sooty surfaces, remove bristle assembly from rubber socket, wash in warm soapy water; let dry before replacing.

B. CREVICE TOOL: For hard to reach places

Assemble Majestic® for suction cleaning.

Use crevice tool for removing dust and dirt behind cushions in upholstered furniture, mattress tufts and bindings, bed springs, corners of drawers, radiators, and any other place that's hard to reach.


NOTE: When cleaning radiators, use crevice tool for suction first, but if coils are too close together to reach the dirt, hang damp cloth or newspaper behind radiator, assemble Majestic* for blowing and blow dust out onto cloth or paper.

Assembled for blowing, Majestic® unit and crevice tool may be used to defrost your refrigerator, aerate rugs, or inflate party balloons.









ATTACHMENTS

A. BARE FLOOR BRUSH: For hard floors and walls

Assemble Majestic® for suction cleaning.

Ideal for hard-surfaced floors such as tile, linoleum, wood, and concrete floors. The bare floor brush cleans a wide area with one simple stroke. It is also effective in cleaning walls, screens, ceilings, shades, or any flat surface.

NOTE: When cleaning wall surfaces, always work in a straight line from the bottom up.

To clean hard surfaces: Attach brush to end of wand and use in same manner as the power nozzle.

To clean brush: After each use, remove lint, threads, etc., by rubbing open end of hose over brush. If brush is soiled, rinse in mild soap solution and let dry before using on light-colored areas.

B. UPHOLSTERY NOZZLE AND BRUSH:

For upholstery and drapes

Assemble Majestic® for suction cleaning.

To clean overstuffed furniture and mattresses: Use the nozzle without the brush to remove deeply embedded dirt; use the nozzle with brush when fabric is covered with threads, lint, etc.

To clean curtains and drapes: Attach wand to hose. For heavy drapes, attach nozzle only directly to wand. For delicate curtains, use the nozzle and brush. Brush will prevent delicate materials from being drawn into the nozzle.









A. CHANGING THE FILTER CONES

For best performance, replace Cones as recommended by manufacturer:

- **▼** BioCone[™] Filter every month
- ▼ MEDIpure®- every 6 months
- ▼ Flat Disc Filter every 6 months

CAUTION - DO NOT operate your power unit without Filter Cones in place.

BEWARE OF IMITATIONS: Use only Genuine Health-Mor/FILTERQUEEN Filter
Cones. Imitations can result in poor performance and cause damage to your unit.

- 1. Unplug power cord from wall and detach hose from power unit.
- 2. Release side clamps and remove power unit from dirt container.
- 3. Remove MEDIpure® Cone and set aside or discard if installing new Cone.
- 4. Empty contents of dirt container into a large, open garbage bag. Allow contents of container to fall including used BioCone™ Filter. Dirt container may be washed and thoroughly dried to remove all dust and/or any odors.
- 5. Open a new BioCone™ Filter. Insert point of Cone into Filter Cone locator in the bottom of the dirt container. Be sure all edges of the Cone are even with the gasket of the dirt container.
- 6. Place the MEDIPure® Cone inside the BioCone™ Filter.
- 7. Replace power unit and lock side clamps in place. Be sure all three tabs of the BioCone™ Filter are visible outside the power unit.

B. CHANGING THE FLAT DISC FILTER

- 1. Unplug power cord from wall and detach hose power unit.
- 2. Release side clamps and remove power unit from dirt container.
- 3. Remove the Cone guard. Next, remove the Flat Disc Filter by pulling back the plastic retainer ring with your finger and lifting it out.
- 4. Replace Flat Disc Filter. Place the filter over the center section of the screen. Replace the retainer ring by squeezing ring. Make sure ring fits snugly under the three tabs of the plastic screen. Replace the Cone guard. Be sure the outer edge of the Cone is seated on the rubber lip around the circumference of the power unit and replace screw.

WARRANTY

HMI Industries, Inc. warrants the Majestic® Home Cleaning System canister unit, motor, hose, wand, power nozzle and attachments to be free of defects in material and workmanship for five years from the date of purchase and the power nozzle motor to be free of defects in material and workmanship for three years from the date of purchase. This warranty does not cover: (1) use of the Majestic® for commercial, institutional, professional, rental, or other non-household purposes; (2) ordinary wear items including but not limited to brushes, belts, bearings, seals, and filters; (3) damage occurring through misuse or negligence; (4) damage caused by use on a current or voltage other than stamped on the nameplate; (5) damage resulting from service work performed by other than HMI Industries or its authorized Distributors and/or Service Centers; (6) cost of transportation, pick-up, delivery, house or service calls; and (7) damage caused from use of nongenuine parts and/or filters.

HMI Industries will repair or replace any defective parts under this warranty provided the Majestic® or defective part is returned, transportation prepaid, with written proof of purchase date and serial number, to the authorized Distributor from whom it was purchased or to the Quality Assurance Department, HMI Industries, 13325 Darice Parkway, Unit A, Strongsville Ohio 44149, U.S.A., or, with written authorization from HMI Industries, to any other person authorized to perform warranty service. Information regarding other persons authorized to perform warranty service can be obtained by calling the HMI Industries Customer Relations Department at, 440-846-7800. If the Majestic® or part is found on inspection to be defective in material or workmanship it will be repaired or replaced at the option of HMI Industries and returned to the sender, freight or postage collect. No reimbursement will be made for the replacement of defective parts or service performed during the warranty period if done by anyone other than the authorized Distributor from whom the Majestic® was purchased or by HMI Industries, without first having obtained written authorization from HMI Industries.

This warranty is null and void and of no effect unless all the following conditions are met: (1) the Majestic* was purchased from an authorized Distributor of HMI Industries; (2) the manufacturer's serial number for the Majestic* has not been changed, defaced or removed; (3) The Majestic* has been used at all times in a accordance with the instruction manual and has not been subject to abuse; (4) Only genuine FilterQueen* filters and/or parts have been used with the Majestic*.

Any repair or replacement of a defect or defective part under this warranty will be warranted for one year or until the end of the original warranty period, which ever is longer.

There is no other express warranty applicable to your Majestic*. Implied warranties, including warranties or merchantability and fitness for a particular purpose, are limited in duration to the period of the time during which the express warranty given herein is in effect. All consequential or other damages resulting from breach of this warranty are excluded from coverage under this warranty.

HMI Industries does not assume or authorize anyone to assume any additional liability.

This warranty gives you specific legal rights and you may have other rights which vary from state to state. The invalidation of any limitation of this warranty shall not affect the validity of the remaining portions.

LIFETIME SERVICE BENEFIT

HMI Industries agrees to rebuild or replace the motor of the Majestic® canister and/or the power nozzle motor at any time after the expiration of the original warranty period, subject to the terms and conditions set forth below.

- 1. The Majestic® must be in the possession of the original owner, must have been used for only household purposes, and must be accompanied by proof of purchase. This service policy does not apply to any Majestic® used for commercial, institutional, professional, rental or other non-household uses.
- 2. The Majestic® must be returned, transportation pre-paid, to the authorized Majestic® Distributor from whom it was purchased, or to the Quality Assurance Department, HMI Industries, 13325 Darice Parkway, Unit A, Strongsville Ohio 44149, U.S.A. The owner must pay return transportation charges.
- 3. The Maximum charge for rebuilding the motor of the Majestic® canister will be \$99 US Dollars and the Maximum charge for rebuilding the power nozzle motor will be \$29 US Dollars; this will include the cost of all parts and labor necessary to restore the Majestic® motor and/or the power nozzle motor to the correct operating order. A charge will be made at the then current prices for any parts missing from the Majestic® at the time it is delivered for rebuilding, if such parts are necessary to restore the Majestic® to correct operating condition and any parts needed or requested other than the canister motor and/or the power nozzle motor.

- 4. If there is a defect in material or workmanship in the rebuilding, the Majestic® will be rebuilt again at no charge, provided the Majestic® is returned within two years of the rebuilding to HMI Industries or the authorized Distributor who performed the rebuilding, transportation prepaid. Written proof of the prior rebuilding must accompany the Majestic®.
- 5. The service agreement is void and inapplicable unless all of the following conditions are met:
- a) The Majestic® was purchased from an authorized Distributor;
- b) Proof of Purchase must accompany the unit;
- c) The manufacturer's serial number for the Majestic® has not been changed, defaced or removed;
- d) Damage to the power unit did not occur by reason of misuse, negligence, use on a current or voltage other than that stamped on the nameplate or by use of other than genuine FilterQueen® filter cones or parts.

WEEE Take-Back & Recycling

The EU Directive on Waste Electrical and Electronic Equipment (WEEE) requires that producers of vacuum cleaners and air cleaners sold into EU countries:

- 1. label new vacuum and air cleaners to notify customers that it needs to be recycled
- 2. take back vacuum cleaners and air cleaners from customers at end of life, and
- 3. finance its recycling and reuse.

The WEEE Directive takes effect on August 13, 2005, and manufacturers must meet target objectives for recycling by December, 2006.

WEEE Compliance Statement

Through our authorized distributor, Health-Mor will take back vacuum cleaners and air cleaners for recycling according to the individual EU country recycling requirements at end of product life.



